

**DEPARTMENT OF ELECTRONICS AND
COMMUNICATION ENGINEERING**

Periyar Nagar, Vallam Thanjavur - 613 403, Tamil Nadu, India
Phone: +91 - 4362 - 264600 Fax: +91- 4362 - 264660
Email: headce@pmu.edu Web: www.pmu.edu



**PERIYAR
MANIAMMAI**
INSTITUTE OF SCIENCE & TECHNOLOGY
(Deemed to be University)
Established Under Sec. 3 of UGC Act, 1956 • NAAC Accredited
think • innovate • transform

U24EC203 SENSORS AND ACTUATORS STUDENT CASE STUDY 2025-2026

**TITLE: *1) NANO BIOSENSORS IN
HEALTHCARE***

***2) LiDAR SENSORS IN ADSA IN
AUTOMOBILE INDUSTRIES***

Submitted By:

KIRUBHASHREE.S

1240110131229

ELECTRONICS AND COMMUNICATION ENGINEERING

STUDENT CASE STUDY ON SENSORS

Table of Contents

ABSTRACT (NANO-BIOSENSOR)	3
1.INTRODUCTION (NANO-BIOSENSOR)	3
2.OBJECTIVE (NANO-BIOSENSOR).....	3
3.TECHNOLOGY USED (NANO-BIOSENSOR)	3
4.WORKING PRINCIPLE (NANO-BIOSENSOR).....	4
5. REAL-TIME APPLICATION (NANO-BIOSENSOR)	4
6.ADVANTAGE (NANO-BIOSENSOR)	5
7. CHALLENGES (NANO-BIOSENSOR)	5
8.CASE ANALYSIS (NANO-BIOSENSOR)	6
Early Detection of EGFR-Positive Lung Adenocarcinoma.....	6
9.CONCLUSION (NANO-BIOSENSOR).....	6
ABSTRACT (LiDAR SENSOR)	7
1.INTRODUCTION (LiDAR SENSOR)	7
2.OBJECTIVE (LiDAR SENSOR)	7
3.TECHNOLOGY USED (LiDAR SENSOR)	7
4.WORKING PRINCIPLE(LiDAR SENSOR)	8
5.REAL-TIME APPLICATION (LiDAR SENSOR).....	8
6.ADVANTAGES (LiDAR SENSOR)	8
7.CHALLENGES (LiDAR SENSOR)	9
8.CASE ANALYSIS (LiDAR SENSOR).....	10
Highway Pilot with Automatic Lane Change	10
9.CONCLUSION (LiDAR SENSOR)	10

ABSTRACT (NANO-BIOSENSOR)

Liquid biopsy, the analysis of tumor-derived biomarkers in blood, is revolutionizing cancer diagnostics. However, detecting ultra-rare biomarkers like circulating tumor DNA (ctDNA) in early-stage cancer remains a significant challenge. This case study explores the application of nano-biosensors—miniaturized devices combining nanotechnology and biorecognition elements—to overcome this limitation. We detail their working principle, advantages in sensitivity and speed, and a hypothetical case example demonstrating their potential for non-invasive, early detection of lung cancer, ultimately leading to timely intervention.

1.INTRODUCTION (NANO-BIOSENSOR)

Traditional cancer diagnosis often relies on invasive tissue biopsies, which can be risky, painful, and fail to capture tumor heterogeneity. Liquid biopsy offers a minimally invasive alternative by analyzing biomarkers (e.g., ctDNA, exosomes, CTCs) released into the bloodstream. The core challenge is that these biomarkers are present in extremely low concentrations, especially in early-stage disease. Nano-biosensors, with their high surface-to-volume ratio and unique optical/electrical properties, are engineered to detect these subtle signals with unprecedented precision.

2.OBJECTIVE (NANO-BIOSENSOR)

The primary objective of deploying nano-biosensors in liquid biopsy is to achieve highly sensitive, specific, and rapid detection of cancer-associated biomarkers from a small blood sample to enable:

- Early-stage cancer diagnosis.
- Real-time monitoring of treatment response.
- Detection of minimal residual disease (MRD) post-treatment.

3.TECHNOLOGY USED (NANO-BIOSENSOR)

- Transducer Platform: Electrochemical or optical (e.g., surface plasmon resonance - SPR).

STUDENT CASE STUDY ON SENSORS

- **Nanomaterial:** Gold nanoparticles, graphene, carbon nanotubes, or quantum dots.
- **Biorecognition Element:** Single-stranded DNA probes, antibodies, or aptamers specific to a cancer mutation (e.g., EGFR L858R).

4. WORKING PRINCIPLE (NANO-BIOSENSOR)

1. **Functionalization:** The nano-biosensor's surface is coated with a biorecognition element (e.g., a DNA probe) designed to bind specifically to a target cancer biomarker (e.g., mutated ctDNA).
2. **Sample Introduction:** A processed blood plasma sample is applied to the sensor.
3. **Binding Event:** The target ctDNA binds to the probe on the sensor surface.
4. **Signal Transduction:** This binding event alters a physical property of the nanomaterial.
 - *Electrochemical:* Binding causes a measurable change in electrical current or impedance.
 - *Optical (SPR):* Binding shifts the angle of reflected light, which is detected.
5. **Detection & Analysis:** The signal is converted into a digital output, confirming the presence and concentration of the target biomarker.

5. REAL-TIME APPLICATION (NANO-BIOSENSOR)

- **Early Screening:** For high-risk individuals (e.g., heavy smokers).
- **Therapy Selection:** Identifying specific mutations (e.g., in EGFR, KRAS) to guide targeted therapy.
- **Recurrence Monitoring:** Periodic blood tests to detect cancer return long before clinical symptoms or imaging.

6. ADVANTAGE (NANO-BIOSENSOR)

- **Ultra-Sensitive:** Capable of detecting biomarkers at femtomolar (10^{-15} M) concentrations.
- **Rapid Results:** Provides results in minutes to hours, unlike days for sequencing.
- **Minimally Invasive:** Requires only a blood draw.
- **High Specificity:** Low rate of false positives due to specific probe-target binding.
- **Portability:** Potential for developing point-of-care devices.

ILLUSTRATION OF SCHEMATIC VIEW OF THE ELECTROCHEMICAL NANO-BIOSENSOR




Figure 1(NANO-BIOSENSOR FOR CANCER DETECTION)

7. CHALLENGES (NANO-BIOSENSOR)

- **Sample Complexity:** Blood contains numerous molecules that can cause non-specific binding and "biofouling."

STUDENT CASE STUDY ON SENSORS

- **Standardization:** Reproducing sensor fabrication and results across different batches and labs is difficult.
- **Clinical Validation:** Requires large-scale clinical trials to prove clinical utility and gain regulatory approval.
- **Cost of Development:** Initial R&D and manufacturing costs are high

8.CASE ANALYSIS (NANO-BIOSENSOR)

Early Detection of EGFR-Positive Lung Adenocarcinoma

- **Patient Profile:** A 62-year-old former smoker with a persistent cough.
- **Challenge:** CT scan shows a small, indeterminate nodule. A tissue biopsy is high-risk due to the nodule's location.
- **Solution:** A liquid biopsy is performed using an electrochemical nano-biosensor functionalized with a probe for the EGFR L858R mutation.
- **Procedure & Result:** A 2 mL blood sample is drawn and processed. The plasma is applied to the sensor, which detects a low but significant level of EGFR L858R mutant ctDNA within 30 minutes.
- **Outcome:** The positive liquid biopsy result provides strong evidence of a malignant, actionable mutation. The patient is immediately started on a targeted EGFR inhibitor (e.g., Osimertinib), avoiding an invasive procedure. Subsequent imaging shows tumor shrinkage, confirming treatment efficacy.

9.CONCLUSION (NANO-BIOSENSOR)

Nano-biosensors represent a paradigm shift in liquid biopsy, offering the sensitivity and speed required to translate this concept into a practical tool for early cancer detection and management. While challenges in standardization and validation remain, the technology's potential to enable non-invasive, personalized, and proactive oncology care is immense. As research progresses, nano-biosensors are poised to become a cornerstone in the fight against cancer.

ABSTRACT (LiDAR SENSOR)

The evolution towards autonomous vehicles relies heavily on robust perception systems. LiDAR (Light Detection and Ranging) has emerged as a critical sensor, complementing cameras and radar. This case study examines the role of LiDAR in ADAS, detailing how it creates high-resolution 3D maps of a vehicle's environment to enable advanced levels of automation. We explore its technology, working principle, and a real-world application in highway piloting, highlighting its advantages in object detection and challenges related to cost and environmental factors.

1.INTRODUCTION (LiDAR SENSOR)

Modern ADAS, from adaptive cruise control to fully autonomous driving, require a precise and reliable understanding of the surrounding world. While cameras provide rich 2D visual data and radar offers robust velocity measurement, they can struggle with accurately perceiving depth and identifying static objects. LiDAR fills this gap by providing a precise, three-dimensional point cloud map of the environment, making it a cornerstone for high-level automation (SAE Levels 3-5).

2.OBJECTIVE (LiDAR SENSOR)

The primary objective of integrating LiDAR into automotive ADAS is to generate a real-time, high-fidelity 3D model of the vehicle's surroundings to enable:

- Accurate detection, classification, and distancing of objects (vehicles, pedestrians, cyclists).
- Robust mapping of the static environment, including road curvature, barriers, and debris.
- Redundant and complementary sensing to cameras and radar for enhanced safety and reliability.

3.TECHNOLOGY USED (LiDAR SENSOR)

- **Type:** Solid-State LiDAR (for automotive integration, more compact and durable than earlier mechanical versions).
- **Laser Source:** Near-infrared (NIR) laser beams, typically at 905nm or 1550nm wavelengths.

STUDENT CASE STUDY ON SENSORS

- **Detector:** Avalanche Photodiodes (APDs) or Single-Photon Avalanche Diodes (SPADs).
- **Scanner:** MEMS (Micro-Electro-Mechanical Systems) mirrors or optical phased arrays to steer the laser beam without moving parts.

4.WORKING PRINCIPLE(LiDAR SENSOR)

- **Emission:** The LiDAR sensor emits rapid pulses of invisible laser light in a wide field of view (e.g., 120° horizontally).
- **Reflection:** These laser pulses strike objects in the environment and reflect back to the sensor.
- **Detection:** The sensor's detectors measure the time-of-flight (ToF)—the time taken for each laser pulse to return.
- **Point Cloud Generation:** Using the speed of light, the system calculates the distance to each point. By combining millions of these distance measurements per second, it constructs a real-time, high-resolution 3D map known as a "point cloud."

5.REAL-TIME APPLICATION (LiDAR SENSOR)

- **Highway Autopilot:** Navigating hands-free on mapped highways.
- **Automatic Emergency Braking (AEB):** Reliably detecting non-metallic objects like pedestrians at night.
- **Traffic Jam Assist:** Navigating and maintaining safe distances in slow, congested traffic.
- **Free Space Detection:** Mapping the drivable area around the vehicle, especially off-road or in complex urban scenes.


6.ADVANTAGES (LiDAR SENSOR)

- **High Resolution:** Creates detailed 3D shapes, allowing for better object classification.
- **Accurate Depth Perception:** Provides precise distance measurements to all objects, static or dynamic.
- **Operates in Low Light:** Performance is independent of ambient light, functioning equally well day and night.
- **Complements Other Sensors:** Provides data that is immune to the limitations of cameras (e.g., low light, sun glare) and radar (e.g., poor resolution).

7. CHALLENGES (LiDAR SENSOR)

- **Cost:** Historically a major barrier, though solid-state designs are reducing costs significantly.
- **Performance in Adverse Weather:** Rain, fog, and snow can scatter laser beams, reducing effective range and clarity.
- **Data Processing:** Generating enormous amounts of data that require significant computational power to process in real-time.
- **Interference:** Potential for crosstalk between LiDARs from multiple vehicles in close proximity.

ILLUSTRATION OF ADAS:



8.CASE ANALYSIS (LiDAR SENSOR)

Highway Pilot with Automatic Lane Change

- **Scenario:** A vehicle equipped with a front-facing LiDAR is driving on a highway using its Level 3 automated driving system.
- **Challenge:** The car needs to automatically change lanes to overtake a slower-moving truck. It must verify the adjacent lane is clear of vehicles, including those in the blind spot.
- **Solution:** The LiDAR continuously scans the environment. As the driver activates the turn signal, the system uses the LiDAR's point cloud to precisely track the position and speed of the truck ahead and a car approaching from behind in the adjacent lane.
- **Procedure & Result:** The LiDAR data fuses with camera and radar data. The system calculates that the approaching car in the adjacent lane is at a safe distance and accelerating slowly. It determines it is safe to change lanes and executes a smooth lane change maneuver, maintaining a safe buffer from both the truck and the car behind.
- **Outcome:** The maneuver is completed safely and comfortably, demonstrating how LiDAR's precise spatial awareness is critical for complex driving decisions.

9.CONCLUSION (LiDAR SENSOR)

LiDAR is no longer a futuristic technology but an increasingly vital component of the automotive sensor suite for high-level ADAS. Its unique ability to provide accurate 3D environmental modeling is essential for achieving the safety and reliability standards required for autonomous driving. While challenges like cost and weather performance persist, ongoing advancements in solid-state technology and sensor fusion algorithms are solidifying LiDAR's role in the future of mobility.